



User Guide

Konftel 60W Conference Unit

US English

Conference phones for every situation





The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such trademarks by Konftel is under license. Other trademarks and trade names belong to their respective owners.


## OmniSound®

This product is equipped with OmniSound®, the crystal clear sound.

<b>WARNING:</b> To reduce the risk of fire or shock hazard, do not expose this product to rain or moisture.		
	<b>CAUTION</b>	
<b>RISK OF ELECTRIC SHOCK DO NOT OPEN</b>		
<b>CAUTION: TO REDUCE THE RISK OF ELECTRICAL SHOCK, DO NOT REMOVE COVER OR BACK. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.</b>		
	The lightning symbol is intended to alert you to the presence of uninsulated dangerous voltage within this product's enclosure that might be of sufficient magnitude to constitute a risk of electric shock. Do not open the product's case.	
	The exclamation symbol is intended to inform you that important operating and maintenance instructions are included in the literature accompanying this product.	

<b>Description</b>	<b>2</b>
Maintenance .....	3
<b>Using Bluetooth</b>	<b>4</b>
Connecting and settings .....	4
Answering a call .....	7
Making a call.....	7
During a call .....	8
Ending a call .....	9
After calls .....	9
Advanced functions .....	10
<b>Using a system telephone</b>	<b>12</b>
Connecting and settings .....	12
Answering a call .....	14
Making a call.....	14
During a call .....	14
Ending a call .....	15
<b>Using a computer</b>	<b>16</b>
General.....	16
Connecting via a sound card .....	16
<b>Other connection options</b>	<b>20</b>
Connecting a computer using a USB Adapter (accessory) ..	20
Connecting a computer using Bluetooth (accessory).....	21
Connecting to a mobile or DECT telephone via a cable (accessory) .....	23
<b>Extra microphones (accessory)</b>	<b>24</b>
<b>Troubleshooting</b>	<b>26</b>
Connection .....	26
Sound .....	27
<b>Technical data</b>	<b>28</b>
<b>Accessories</b>	<b>30</b>
Order numbers for accessories.....	30
Limited Warranty .....	31
<b>Warranty, service, FCC and IC statement</b>	<b>31</b>
Service Agreements .....	32
FCC Statement.....	33
Industry Canada (IC) Statement.....	34

# DESCRIPTION



Konftel 60W is a conference unit for connecting to existing fixed system telephones, DECT telephones, cell phones or computers, with a cable or wireless connection via Bluetooth. Konftel 60W has an omnidirectional, highly-sensitive microphone and three speakers which, together with Konftel's OmniSound® provide optimal sound quality and maximum reduction of room echo, even when the person speaking is standing at a slight distance from the unit.

Konftel 60W has five buttons. The most common functions for power, speaker volume and mute are obvious, but all the buttons have other functions for activating various special functions and settings. Therefore, you should read the sections of the handbook that deal with the connections you intend to use so that you do not miss any important options.

**Plug adapter**

Connection cable  
electricity–mains  
socket





Outlets for extra  
microphones

Cable duct

Line connection

Power supply


Holes for  
wall bracket




Connection cable  
electricity,  
19ft (6m)  
(60W–plug adapter)

Switchbox

(60W–telephone handset)



Connection cable  
telephone, 9ft (3m)  
(60W–switchbox)



Connection cable  
computer, 4ft (1.5m)  
(60W–computer)



Konftel's website [www.konftel.com](http://www.konftel.com) offers suggestions for various applications and accessories for the 60W and other products.


Konftel 60W is designed to handle headset and handsfree profiles as per Bluetooth standard 1.1. Please note that not all telephones support all functions. More information is contained in your telephone handbook.

If the GSM network has reduced functionality, e.g. due to poor coverage, the sound quality may be affected. This is not due to the Konftel 60W.

## MAINTENANCE

Clean the equipment with a soft, dry cloth. Never use liquids.

# USING BLUETOOTH



## CONNECTING AND SETTINGS

⇒ Plug Konftel 60W in the mains using the power adapter as shown in the picture.

### General information on Bluetooth

In order for two Bluetooth units to be able to communicate with each other, they must first be “paired”, which means that the second unit is added to a list of added units. Your Bluetooth telephone has a menu where added units are displayed and where you can, for instance, choose between various Bluetooth headset and handsfree options.

Familiarize yourself with your telephone's functions by reading through this handbook. In the instructions below, we do not deal with how to use your telephone as this varies between various makes and models.

Please note!

The Bluetooth protocol, which is used by the units to communicate, has a number of commands to activate functions, end calls, etc. Some do not function fully on all telephones. You should therefore check, for instance, that the telephone has actually disconnected the call if you do this by pressing a button on Konftel 60W.

Bluetooth has a range of up to ten meters. The best performance is achieved when the distance does not exceed five meters.

## Adding your telephone and retaining other stored telephones

Konftel 60W can store up to eight telephones. If you want to retain previous pairings and add a new one, follow the instructions below. If you want to remove a previous pairing, go to the next section.

If you store a ninth telephone, the telephone first stored is automatically deleted.

Please note that Konftel 60W should not be switched on when pairing.



⇒ Press and hold the **+** and **trim** buttons for 2 seconds until the blue LEDs start flashing.

⇒ Follow the instructions in your telephone handbook to add a new Bluetooth unit.

⇒ Select **Konftel 60W** from the list of units detected.

⇒ Enter the password **0000**.

If the pairing was successful, a short audible signal will be heard and the LEDs will stop flashing.

Please note that Konftel 60W is normally added as a *headset*. This will not work for certain telephones (Konftel 60W is not displayed as an available Bluetooth unit on the telephone). You can then choose instead to add Konftel 60W as a *handsfree* unit by pressing and holding the button for 4 seconds instead of 2 in the display. The blue LEDs then start flashing more slowly.

## Adding your telephone and deleting other stored telephones



- ⇒ Press and hold the **trim** button for 2 seconds until the blue LEDs start flashing.
- ⇒ Follow the instructions in your telephone handbook to add a new Bluetooth unit to your telephone.
- ⇒ Select **Konftel 60W** in the list of units detected.
- ⇒ Enter the password **0000**.

If the pairing was successful, a short audible signal will be heard and the LEDs will stop flashing.


## Removing all pairing information from Konftel 60W



- ⇒ Press and hold the - and + buttons at the same time for 2 seconds until you hear a short sound signal.

## Adjusting the microphone sensitivity

The microphone volume can be adjusted during a call, but to avoid disturbing the call, it may be best to adjust it during a test call after the telephone has been paired. The volume can be adjusted in 5 steps. Please note that different telephones may have different volumes and the microphone volume on Konftel 60W may need to be adjusted if you connect a different make of telephone.



- ⇒ Press and hold the **mute** button for 2 seconds until the LEDs start to flash and you hear a tone.
- ⇒ Increase the microphone volume using the + button and reduce it using -.

Adjust the microphone volume one step at a time until you can hear well at the other end. Please note that too high a volume may cause echoes and feedback.



⇒ Press the **mute** button to conclude setting the selected microphone volume.

## Changing the ringtone

The LEDs start flashing when there is an incoming call. You can also activate a ringtone in Konftel 60W.



⇒ Press and hold the – button for 2 seconds to activate the ringtone for incoming calls.

Follow the same procedure to deactivate it again.

## ANSWERING A CALL



⇒ Press the **on/off** button when Konftel 60W rings (the LEDs flash).

The ring signal in the telephone may be heard before it is heard in Konftel 60W. Wait until Konftel 60W rings (the LEDs flash) before pressing the on/off button.

## MAKING A CALL



⇒ Make a call with your telephone in the normal way.

⇒ Transfer the call to Konftel 60W as per the instructions in the telephone handbook.

If you have programmed Konftel 60W to function as a telephone headset, the call is normally transferred there automatically as long as the Bluetooth connection is activated.


## DURING A CALL

### Transferring a call between Konftel 60W and a telephone



⇒ Press and hold the **on/off** button for 2 seconds to transfer the call back to your telephone.

### Adjusting the speaker volume



⇒ Increase the speaker volume using **+** and reduce it using **-**.

There are 15 volume settings. Please note that the telephone's volume setting also affects the speaker volume in Konftel 60W.

### Mute function



⇒ Press the **mute** button to turn the microphone off.

The LEDs change from blue to red. The other party cannot hear what you are saying.



⇒ Press the **mute** button to turn the microphone back on.

### Tuning the sound manually

Konftel 60W adjusts itself automatically when you switch it on to eliminate echo. It also senses changes in the room and continually adapts during the call. If, despite this, you still experience echoes, Konftel 60W can also be tuned manually at any time.



⇒ Press **trim**.

A short audible signal is heard.

## ENDING A CALL



⇒ Ending the call on your telephone.

Konftel 60W switches off automatically. The call can also be ended by pressing **on/off**.

## AFTER CALLS

### Disconnecting the Bluetooth link

The Bluetooth link between the telephone and Konftel 60W is kept open until it is disconnected or until the units are out of range of each other. If you do not intend to use the phone for a while, you can choose to disconnect the link to save power.



⇒ Press the **mute** button to disconnect the Bluetooth link.

The link is automatically connected when the telephone rings or you make a call.

You can also disconnect Bluetooth using the mobile phone menu system. More information on this is contained in the telephone handbook.

### Deactivating Bluetooth

If you choose to deactivate Bluetooth on Konftel 60W, all Bluetooth communication is turned off until you choose to re-activate it.



⇒ Press and hold the **on/off** and – buttons for 2 seconds to deactivate Bluetooth

⇒ Press and hold the **on/off** and – buttons for 2 seconds to activate Bluetooth again.

## ADVANCED FUNCTIONS

These functions are only available if the telephone supports them.


### Last number redial



- ⇒ Press and hold the **mute** button for 2 seconds until you hear a short audible signal.

### Making a call using voice command


This is a function you can normally activate on your telephone. If you have done this, you can also initiate voice dial mode from Konftel 60W. More information on voice dialing is contained in the telephone handbook.




- ⇒ Press the **+** button for 2 seconds until you hear a short audible signal.
- ⇒ Say the name of the person you wish to call.

### Answering another call

This requires you to have set the telephone to receive other calls during ongoing calls. You can also use the buttons on your telephone to answer another call.



- ⇒ Press the **+** button for 2 seconds to put the current call on hold and receive the incoming one.



- ⇒ Select between the calls by pressing the **+** button for 2 seconds.


You can choose to end the current call and receive the incoming one (or the call on hold if you have already received a new call as above).



- ⇒ Press the **trim** button for 2 seconds to end the current call and receive the incoming one.

## Multi-party calls

Once you have answered another call as per the previous section, you can add them to a multi-party call.



⇒ Press and hold the - and + buttons at the same time for 2 seconds.


## Rejecting a call



⇒ Press and hold the **on/off** button for 2 seconds until you hear a short audible signal.

If you already have an active call, you can reject another incoming call in the same way.

# USING A SYSTEM TELEPHONE



## CONNECTING AND SETTINGS

- ⇒ Connect Konftel 60W to the telephone via the switchbox as per the pictures above.
- ⇒ Plug Konftel 60W in using the power adapter as shown in the picture.
- ⇒ Make a test call to check that everything works and to adjust the microphone setting.


Please note that the selector switch for different types of telephone is located on the bottom of the switchbox. See troubleshooting for more information if something does not work.

## Using a headset instead of the handset

You can connect a headset to the switchbox instead of a handset. Please note that the headset must be suitable for the telephone system.

## Adjusting the microphone sensitivity

The microphone volume can be adjusted during the call, but to avoid disturbing the call, it may be best to adjust it during a test call following connection. There are 5 volume settings.



⇒ Press and hold the **mute** button for 2 seconds until the LEDs start to flash and you hear a tone.

⇒ Increase the microphone volume using the **+** and reduce it using **-**.

Adjust the microphone volume one level at a time until you can hear well in the other end. Please note that too high a level may cause echoes and feedback.

⇒ Press the **mute** button to conclude setting the selected microphone volume.

## ANSWERING A CALL



- ⇒ Answer the call using the telephone in the normal way.
- ⇒ Press the **on/off** button to switch on Konftel 60W and change to speaker call.
- ⇒ Place the handset to one side – it is now disconnected.

## MAKING A CALL



- ⇒ Lift the handset and dial the number.
- ⇒ Press the **on/off** button to switch on Konftel 60W and change to speaker call.
- ⇒ Place the handset to one side – it is now disconnected.

## DURING A CALL

### Transferring a call between Konftel 60W and a telephone



- ⇒ Press the **on/off** to switch off Konftel 60W and transfer the call back to the telephone.

### Adjusting the speaker volume



- ⇒ Increase the speaker volume using **+** and reduce it using **-**.

There are 15 volume settings. Please note that the telephone's volume setting also affects the speaker volume in Konftel 60W.



## Mute function

⇒ Press the **mute** button to turn off the microphone.

The LEDs change from blue to red. The other party cannot hear what you are saying.



⇒ Press the **mute** button again to switch the microphone back on.

## Tuning the sound manually

Konftel 60W adjusts itself automatically when you switch it on to eliminate echo. It also senses changes in the room and continually adapts during the call. If, despite this, you still experience reduced sound quality, Konftel 60W can be tuned manually at any time.



⇒ Press **trim**.

A short audible signal is heard.

## ENDING A CALL



⇒ Hang up the handset.



⇒ Press the **on/off** button to turn off Konftel 60W.

# USING A COMPUTER

## GENERAL

Konftel 60W functions as a speaker and microphone for all computers that have a microphone input and a line output for sound. Konftel 60W can also be connected via a USB sound card or wirelessly via Bluetooth. The manner of connection may require accessories and is described in the section *Other connection options* on pages 20–21.


## Use

You can use Konftel 60W for programs that communicate over the Internet (e.g. Skype). You make, answer and end calls in the program. Konftel 60W functions as a speaker and microphone when it is switched on.

The buttons for mute and manual tuning also function when connected to a computer (see page 15).

## CONNECTING VIA A SOUND CARD

Connect in the order shown on the next page.



- ⇒ Connect Konftel 60W to the sound card using the accompanying Y-cable as per the picture.

LINE OUTPUT ----- OUT --- Green  
 MICROPHONE INPUT - IN ----- Pink

- ⇒ Plug Konftel 60W in using the power adapter as shown in the picture.



- ⇒ Start the computer and switch on Konftel 60W (the **on/off button**).

- ⇒ Check and adjust the computer's sound and volume settings as per the next section.

## Checking the sound unit in Windows

There follows an example of how such items appear on a computer with Windows XP. Please note that it may look different on your computer. In a Macintosh you open the computer's system settings to select sound inputs and adjust sound levels.



- ⇒ Open **Properties** for **Sound and Audio Devices**. (Right click on the speaker symbol in the Activity field and select **Adjust Audio Properties** from the quick menu or use the start menu: **Start > Control panel > Sound and Audio Devices**.)
- ⇒ Click on the **Audio** tab and check that the computer's **sound card** is selected as the standard unit. Otherwise you must actively select the computer's sound card in your application (e.g. Skype®) each time you re-start the computer.



## Adjust the speaker volume in Windows

⇒ Click on the **Volume...** button under **Sound playback** on the tab **Audio**.

⇒ Adjust the sound level for **Volume Control** so that it is between the intermediate and maximum level.

This setting adjusts the line output level from the computer. A low sound level here means that you must increase the volume on Konftel 60W to the maximum level, which may lead to fuzzy sound and a low sound level. A high sound level means that the volume on Konftel 60W can be set to an intermediate setting and still produce excellent sound through the speakers.

⇒ Check the sound level when you playback sounds (any sound source in the computer). Please note that Konftel 60W must be switched on.

Note that you also have separate volume controls for various sound sources in the computer. These volume controls apply to playback from each sound source. Choose **Mute** for microphone input if you do not want to hear your own voice through the speakers. A high volume may cause echoes and feedback.

## Adjusting the speaker volume on Konftel 60W

If necessary, the volume on Konftel 60W can be adjusted during a call.

⇒ Increase the speaker volume using **+** and reduce it using **-**.

There are 15 volume settings.



## Adjusting the microphone sensitivity in Windows




- ⇒ Click on the **Volume...** button under **Sound recording** on the tab **Audio**.
- ⇒ Adjust the microphone input between the intermediate and maximum level. Connect a call and adjust the volume if required.

It is best to use the communication program you intend to use with Konftel 60W when testing the microphone volume.

## Adjusting the microphone sensitivity on Konftel 60W

Adjust the microphone volume on Konftel 60W if required. There are 5 volume settings. Please note that Konftel 60W must be switched on.




- ⇒ Press and hold the **mute** button for 2 seconds until the LEDs start to flash and you hear a tone.
- ⇒ Increase the microphone volume using **+** and reduce it using **-**.

Adjust the microphone volume one level at a time until the correct level is achieved.

- ⇒ Press the **mute** button to conclude setting the selected microphone volume.

## OTHER CONNECTION OPTIONS




### CONNECTING A COMPUTER USING A USB ADAPTER (ACCESSORY)

The USB adapter functions as a sound card in a computer without inputs and outputs for sound.

- ⇒ Connect the USB adapter to Konftel 60W as shown in the picture.  
Green plug --Output labelled SPK on USB adapter  
Pink plug ----Output labelled MIC on USB adapter
- ⇒ Connect the USB adapter to a USB port on the computer as shown in the picture.
- ⇒ Plug Konftel 60W in using the power adapter as shown in the picture.
- ⇒ Check the sound properties and adjust the sound volume in the same way as for a computer with built-in inputs and outputs for sound (see pages 17–19).

Please note that you must ensure that a **USB headset** is specified as the standard unit. Otherwise you must actively select USB headset as a sound unit in your application (e.g. Skype®) each time you re-start the computer.



### CONNECTING A COMPUTER USING BLUETOOTH (ACCESSORY)

If the computer has a built-in Bluetooth or is equipped with a USB Bluetooth adapter, it can be connected wirelessly to Konftel 60W provided it is within the range for Bluetooth.

Note that some computers and Bluetooth adapters do not support headset functions and are only intended for communication with mobile phones, hand-held computers, mice and keyboards. If possible, use Konftel's own adapter, sold as an accessory.

⇒ Plug Konftel 60W in using the power adapter as shown in the picture.



### Pairing with a Bluetooth-equipped computer

Read the section “General information on Bluetooth” on page 4 if you are unsure about what pairing involves.


- ⇒ Press and hold the **trim** button for 2 seconds until you hear an audible signal and the blue LEDs start flashing.
- ⇒ Choose to search for new Bluetooth units in the Windows control panel.
- ⇒ Select **Konftel 60W** in the list of units detected.
- ⇒ Enter the password **0000**.

If the pairing was successful, a short audible signal will be heard and the LEDs will stop flashing. (Page 5 contains information on the handsfree and headset profile if pairing fails.)

### Checking the sound properties in Windows

- ⇒ Check the sound properties and adjust the sound volume in the same way as for a computer with built-in inputs and outputs for sound (see pages 17–19).

Please note that you must ensure that **Bluetooth Audio** is specified as a standard unit. Otherwise you must actively select Bluetooth Audio as a sound unit in your application (e.g. Skype) each time you re-start the computer.



### CONNECTING TO A MOBILE OR DECT TELEPHONE VIA A CABLE (ACCESSORY)


The Konftel 60W can be connected to a GSM or wireless DECT telephone using an accessory cable, as illustrated. Cables are available for most models on the market. Visit [www.konftel.com](http://www.konftel.com) for more information on accessories.

- ⇒ Plug Konftel 60W in using the power adapter as shown in the picture.
- ⇒ Connect the telephone to Konftel 60W as shown in the picture.
- ⇒ Adjust the microphone and speaker volume in the same way as when connecting to system telephones (see pages 13–14).

#### Use

See pages 15–16 for descriptions of how to make and answer calls and how the mute and tuning functions work.

## EXTRA MICROPHONES (ACCESSORY)



### Connecting and settings

For a reception area up to 70 m<sup>2</sup>, Konftel 60W can be quickly and simply supplemented with two extra microphones. The extra microphones are supplied with two different cable sets, 4 and 8 ft (1.5 and 2.5 m).

- ⇒ Place the extra microphones at least 3 ft (0.8 m) and no more than 9 ft (2.5 m) from Konftel 60W and connect them using the accompanying cables.

A short audible signal specifies that the connection has been successfully established and that the software in Konftel 60W has been upgraded. The microphone in Konftel 60W is now disconnected.

### Adjusting the speaker volume



- ⇒ Press the **up** or **down** button on one of the extra microphones to adjust the speaker volume.

### Manual tuning



- ⇒ Press the **up** and **down** buttons at the same time for manual tuning (see page 8).

A short audible signal is heard.

### Mute function



⇒ Press the **mute** button on one of the extra microphones to switch off the microphones.

The LEDs change from blue to red. The other party cannot hear what you are saying.



⇒ Press the **mute** button again to switch the microphones back on again.

# TROUBLESHOOTING

A number of problems that may arise when connecting and using Konftel 60W are described below.

## CONNECTION

### Bluetooth


1. If Konftel 60W is not displayed when you try to add a new unit to the telephone, or if any particular Bluetooth function is not working, Konftel 60W may need to be presented as a handsfree unit instead of a headset. Repeat the instructions for “Adding your telephone” on page 5, except this time press and hold the **trim** button for 4 seconds instead of 2.

### System telephone via switchbox

1. Is Konftel 60W correctly connected? See the instructions for connecting the telephone.
2. Have you added extension cords to the system? Remove them and re-connect to see if the system is working.
3. Check the position of the selector switch on the bottom of the switchbox. Select position **I** or **II** depending on which system telephone you are connecting Konftel 60W to.

Manufacturer	Type of switchboard	Selector switch position
--------------	---------------------	--------------------------

ERICSSON	MD110	I
	BUSINESS PHONE	I
NORTEL	MERIDIAN 1	I
	COSMOS	I
PHILIPS	SOPHO	II
	ERGOLINE	I
ALCATEL	4200	I
	4400	I
SIEMENS	HIPATH	I
	HICOM	I



For other types of switchboard, try position I first, and then position II.

## Computers

If a call can be heard via the computer's headset or built-in speaker, but not via Konftel 60W, check that the software and sound card can handle full duplex.

## SOUND

### No sound

1. Are the LEDs red? If so, the mute button is activated. Press to deactivate.

### Poor sound quality, echo

1. Check that Konftel 60W is within the range for the telephone.
2. Check the position. The unit is intended to stand flat on a table. Avoid moving the unit around during a call. Do not place the unit too close to a wall or underneath objects such as lampshades or pot plants.
3. Tune Konftel 60W manually. See instructions for manual tuning.
4. Is the volume correctly adjusted? See the instructions for adjusting the volume setting for the microphone.
5. Is the other party using a conference unit, sound card or software that cannot handle full duplex?

## TECHNICAL DATA

### Konftel 60W

Power supply:	Transformer 12 V DC/230V AC, 700 mA (Europe) Transformer 12 V DC/110V AC, 700 mA (USA)
Inputs:	Analogue line in/out, modular 6/6 Rec (speaker) -10 dBV (adjustable) Broadcast (microphone) -30 dBV (adjustable)
Speaker volume:	Adjusts to 15 levels
Microphone volume:	Adjusts to 5 levels
Room echo reduction:	208 ms
Line echo reduction:	38 ms
Environment:	Reception area <320 sq ft (30 m <sup>2</sup> ) Reverberation time in room <500 ms Background noise <45 dBA Temperature range: 5–40° C
Electrical safety:	UL60950-1 CAN/CSA C22.2 No. 60950 EN60950
RF/EMC:	ETSI EN301489-17 V1.2.1 FCC Part 15 Certificate RSS210 ETSI EN300 328-2 V1.2.1
Telecom:	FCC Part 68 Registration IC CS-03
Dimensions:	Diameter 9.15 inches (232 mm)
Weight:	1.6 pounds (700 grams)

### Switchbox

Input telephone handset:	Modular 4/4
Input Konftel 60W:	Cable, modular 6/6
Output telephone:	Cable, modular 4/4. The contact for connecting a switchbox to a system telephone may only be connected to SELV current in accordance with SS-EN60950
Compatibility:	Can be connected to most system telephones on the market

## Computer cable

Y-cable: 1 x modular 6/4, 2 x Tele 13 inches (3.5 mm). Contact for connecting a Konftel 60W to a computer may only be connected to SELV current in accordance with SS-EN60950

## Extra microphones (accessory)

Cabling: Modular 4/4-contacts, 2x4 ft (1.5m) and 2x8 ft (2.5 m)  
Environment: Temperature range: 5–40° C  
Dimensions: Diameter 4 in (105 mm), height 1 in (30 mm)

## USB adapter for sound (accessory)

USB connection: USB 1.1 Full-speed  
System req. PC: Pentium >200MHz, min 256 MB RAM, spare USB port

## USB Bluetooth adapter (accessory)

Bluetooth connection: 1.2 class 1 and class 2  
USB connection: USB 1.1 Full-speed  
System req. PC: Pentium >200MHz, min 256 MB RAM, spare USB port  
Dimensions (LxWxH): 2x0.7x0.4 in (50x17x10 mm)

## ORDER NUMBERS FOR ACCESSORIES

<b>Item no.</b>	<b>Designation</b>
9146030	Wall mounting bracket
9164032	Extension cord electrical, 32 ft (10 m)
900102038	Extension cord telephone, 32 ft (10 m)
900102058	USB adapter for sound
900102074	Extra microphones (1 pair)
900102067	Soft bag
900102072	USB Bluetooth adapter
	Connection cables GSM/DECT see <a href="http://www.konftel.com">www.konftel.com</a> , under Accessories Konftel 60W

## LIMITED WARRANTY

Konftel guarantees to the end user (the "Customer") that this product will be free from defects in workmanship and materials, under normal use and service, for a period of two (2) years from the date of original purchase from its authorized distributor. Konftel's sole obligation under this express warranty shall be, at Konftel's option and expense, to repair the defective product or part, or deliver to the Customer an equivalent product or part to replace the defective item.

All products that are replaced will become the property of Konftel. Replacement products or parts may be new or reconditioned. Any replaced or repaired product or part carries a ninety (90) days limited warranty or the remainder of the initial warranty period, whichever is longer. Products returned to Konftel must be sent prepaid and packaged appropriately for safe shipment. It is recommended that the package is insured or sent by a method that enables tracking of the package.

Responsibility for loss or damage does not transfer to Konftel until the returned item has been received by Konftel. The repaired or replaced item will be shipped to the Customer, at Konftel's expense, not later than twelve days (12) days after Konftel has received the defective product, and Konftel will retain risk of loss or damage until the item has been delivered to the Customer.

## Exclusions

Konftel shall not be liable under this limited warranty if examination and tests of the returned product reveal that the alleged defect or malfunction in the product does not exist or results from:

- Failure to follow Konftel's installation, operation or maintenance instructions.
- Unauthorized product modification or alteration.
- Unauthorized use of common carrier communication services accessed through the product.
- Abuse, misuse, negligent acts or omissions on the part of the Customer and persons under the Customer's control; or
- Acts of third parties, force majeure, accident, fire, lightning, power surges, outages or other hazards.

WARRANTY EXCLUSIVE: IF A KONFTEL PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY FOR BREACH OF THAT WARRANTY SHALL BE REPAIR OR REPLACEMENT OF THE PRODUCT IN QUESTION AT KONFTEL'S OPTION. TO THE FULL EXTENT ALLOWED BY LAW, THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES, TERMS, OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES, TERMS, OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, SATISFACTORY QUALITY, CORRESPONDENCE WITH DESCRIPTION, AND NON-INFRINGEMENT, ALL OF WHICH ARE EXPRESSLY DISCLAIMED. KONFTEL NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY.

## SERVICE AGREEMENTS

For information on Konftel service agreements, or if you should experience trouble with this equipment, please contact Konftel Support.

**Konftel Support in USA and Canada:**

+1-(866)-606-4728 Monday through Friday 8.00 AM to 5.00 PM Central Standard  
Email: konftel.usa@konftel.com

**Konftel Support International:**

+46-90706489 Monday through Friday 8.00 AM to 5.00 PM (GMT:-1)  
Email: info@konftel.com

**NOTICE:** If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

Please follow instructions for repairing if any; otherwise do not alternate or repair any parts of device except specified.

If you purchased your product from an authorised Konftel distributor, please contact that distributor for information about service agreements that apply for your product.

LIMITATION OF LIABILITY. TO THE FULL EXTENT ALLOWED BY LAW, KONFTEL EXCLUDES FOR ITSELF AND ITS SUPPLIERS ANY LIABILITY, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF KONFTEL OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, AND LIMITS ITS LIABILITY TO REPAIR OR REPLACE AT KONFTEL'S OPTION. THIS DISCLAIMER OF LIABILITY FOR DAMAGES WILL NOT BE AFFECTED IF ANY REMEDY PROVIDED HEREIN SHALL FAIL OF ITS ESSENTIAL PURPOSE.

### Disclaimer

Some countries, states and provinces do not allow the exclusion or limitation of implied warranties or the limitation of incidental or consequential damages for certain products supplied to consumers, or the limitation of liability for personal injury, so the above limitations and exclusions may be limited in their application to you. When the implied warranties are not allowed to be excluded in their entirety, they will be limited to the duration of the applicable written warranty. This warranty gives you specific legal rights which may vary depending on local law.

## FCC STATEMENT

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA. On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:5RWTXNANC1049. If requested, this number must be provided to the telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local telephone company. [For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:5RWTXNANC1049. The digits represented by 05 are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.]

**NOTICE:** If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this Konftel 60W does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

**NOTICE:** According to telephone company reports, AC electrical surges, typically resulting from lightning strikes, are very destructive to telephone equipment connected to AC power sources. To minimize damage from these types of surges, a surge protector is recommended.

### The FCC wants you to know

In the unlikely event that your phone causes problems on the phone line, the phone company can temporarily discontinue your service. If this happens, the phone company attempts to notify you in advance. If advance notice is not practical, the phone company notifies you as soon as possible and advises you of your right to file a complaint with the FCC.

Also, the phone company can make changes to its lines, equipment, operations, or procedures that could affect the operation of this telephone. The telephone company notifies you of these changes in advance, so you can take the necessary steps to prevent interruption of your telephone service.

This equipment complies with the limits for a Class B digital device as specified in Part 15 of FCC Rules. These limits provide reasonable protection against radio and TV interference in a residential area.

However, your equipment might cause TV or radio interference even when it is operating properly. To eliminate interference, you can try one or more of the following corrective measures:

- reorient or relocate the receiving antenna.
- increase the distance between the equipment and the radio or TV.
- use outlets on different electrical circuits for the equipment and the radio or TV.

Consult your local store if the problem still exists.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

**Warning:** Changes or modifications to this phone not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Important note:** It is a legal requirement for you to have the consent of all parties in a conversation before the conversation can be recorded.

## INDUSTRY CANADA (IC) STATEMENT

This product meets the applicable Industry Canada technical specifications.

The Ringer Equivalence Number provides an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

Operation is subject to the following two conditions:

- 1) this device may not cause interference and
- 2) this device must accept any interference, including interference that may cause undesired operation of the device.

## RF EXPOSURE

To assure compliance with FCC rules regarding RF Exposure, this equipment should be installed and operated with a minimum distance of 20 cm from any personnel.



**Konftel** is a leading company within loudspeaker communication and audio technology. We develop and sell products and technology for telephone meetings based on cutting-edge expertise within acoustics and digital signal processing. Characteristic of our products is that all conference telephones contain the same high quality audio technology – OmniSound® – providing crystal clear sound. Learn more about Konftel and our other products on **[www.konftel.com](http://www.konftel.com)**

Developed by Konftel AB  
Box 268, SE-901 06 Umeå, Sweden  
Phone: +46 90 706 489 Fax: +46 90 131 435  
E-mail: [info@konftel.com](mailto:info@konftel.com) Web: [www.konftel.com](http://www.konftel.com)

---