



AT840 series User Manual

Version: 1.2

2013-08-26

Release note

Version	Changed note	Editor	Date
1.0	First Release	Stefen	2013-1-25
1.1	Page 9: Packing List 1. Add Ethernet Cable(1.5m)	Jessie	2013-5-13
1.2	Web Settings -> Account Add parameters description: 1.Session Timer Enable 2.Early Update Enable 3.Caller ID Display 4.AutoSubscribeMWBEnable 5.Server List 6.Dns Mode 7.Blif List Uri 8.G711A 9.G711U 10.AVT 11.G722 12.G723 13.G729ab 14.iLBC 15.G726-16 16.G726-24 17.G726-32 18.G726-40	Jason	2013-8-26

Content

- Contact ATCOM..... 5
- 1. AT840 Series Overview..... 6
 - 1) Interfaces..... 7
 - 2) Hardware..... 7
 - 3) Software..... 7
 - 4) Network..... 8
 - 5) Management and Maintenance..... 8
 - 6) Protocol..... 8
 - 7) Compliant Standard..... 8
 - 8) Operating Requirement..... 9
 - 9) Packing List..... 9
 - 10) Installation..... 9
- 2. Keypad of IP Phone..... 13
 - 1) Describe of the buttons and Screen..... 13
 - 2) BLF indicator status..... 14
- 3. Basic functions and operations..... 15
 - 1) Answer the calls..... 15
 - 2) Make Call..... 15
 - 3) Speed dial..... 16
 - 4) Multiple line dial-up..... 16
 - 5) Hang up the phone..... 16
 - 6) Call Transfer..... 16
 - 7) Message waiting indication(MWI)..... 17
 - 8) Mute calls..... 17
 - 9) Call Hold..... 17
 - 10) 3-Way Conference Calls..... 18
 - 11) Call History..... 18
 - 12) SMS function..... 19
 - 13) Default Password..... 19
 - 14) Check the Phone’s IP..... 20
 - 15) Dial Plan..... 20
- 4. Web settings..... 23
 - 1) System status..... 24
 - 2) Network..... 25
 - 1.1. Basic..... 25
 - 1.2. Advance..... 25
 - 3) SIP Setting..... 27
 - 4) Account..... 29
 - Account1/Account2/Account3/Account4..... 29
 - 5) Phone Setting..... 33
 - 5.1. Preference..... 33

5.2. Line	35
5.3. Features	35
5.4. Voice	37
5.5. Ring.....	38
5.6. Tone	38
5.7. Programmable key	39
5.7. Ext Key	40
6) Update.....	41
6.1. Manual Update	41
6.2. Reset & Reboot	42
7) Phone Book.....	42
8) Call Log.....	43
5. FAQ & Trouble Shooting.....	43
1) Frequently Asked Questions	43
1.1 How to make a factory reset.....	43
1.2 Upgrade firmware under safe mode	43
1.3 How to make direct IP call	44
2) Trouble Shooting.....	44
2.1 The phone can' t register successfully	44
2.2 The phone can' t obtain IP address.....	44
2.3 Only one part can hear the voice during the call	45

Contact ATCOM

The Introduction of ATCOM

ATCOM is the leading VoIP hardware manufacturer in global market. We have been keeping innovating with customer's needs oriented , working with partners to establish a total solution for SMB VoIP with IP phone , IP PBX and Asterisk cards

With over 10 years' experience of R&D , manufacturing and service in network and VoIP filed ; mission of creating the biggest value for IP terminals , we commit ourselves in supplying the competitive IP phone and other terminals for IP PBX , softswitch , IMS , NGN providers and carriers; supplying the competitive total VoIP solution for SMB market. We keep improving the customer's experience and creating the bigger value with our reliable products. Until now , our VoIP products has been sold to over 60 countries and used by millions of end users.

Contact Sales

Address	Area C, A2F , Block 3 ,Huangguan Technology Park , #21 Tairan 9th Rd, Chegongmiao , Futian District , Shenzhen China
Tel	+ (86) 755-83018618-8888
Fax	+ (86) 755-83018319
E-mail	sales@atcomemail.com

Contact Technical Support

Tel	+ (86) 755-83018618-8011
E-mail	Support@atcomemail.com

Website Address: <http://www.atcom.cn/>

Download Center: <http://www.atcom.cn/download.html>

1. AT840 Series Overview

AT840 is almost the same with AT840P without PoE



AT840/AT840P



AT840/AT840P with extension module

Type	PoE	Power adapter
AT840	No	Standard accessory
AT840P	Yes	Optional accessory

1) Interfaces

- Power input: DC 12V, 500mA
- WAN: RJ45 port
- PC: RJ45 port
- EXT: RJ45 port
- Headset jack 1 : RJ9 port
- Handset jack 1 : RJ9 port

2) Hardware

- LCD: 128×64 dot matrix
- FLASH: 8M
- RAM: 32M
- CPU: 262MHz Dual Core
- LED indicator: 1 Status Light , 4 line indicators, 9 BLF indicators, 1 voicemail indicator, 1 headset indicator, 1 mute indicator, 1 hand-free indicator
 - Expander board: 20 BLF keys on each expander board, can connect at most 5 expander boards on a AT840.

3) Software

- Sip 2.0 (RFC3261) and other related SIP RFCs
- 4 SIP lines
- Multi-language
- G.711A/u, G722, G.723, G.726, G.729 , Lin16-16, iLBC Codec
- DTMF inband, RFC2833 and SIP info
- Call Forward, DND(Do Not Disturb), Pickup, Redial, Call Park, Call waiting
- Call transfer, Call hold, 3-way conference
- BLF, SMS, Blacklists, Dial plan, IP to IP call
- Auto answer, Block Anonymous call, Block Call-ID
- STUN, SNTP
- Jitter Buffer,VAD,CNG
- HD voice
- G.168 compliant 96ms echo cancellation
- SIP UDP,TCP, TLS
- Phone book with 200 records, 200 answered calls, 200 missed calls, 200 dialed calls
- Auto update via HTTP, FTP, TFTP
- Syslog
- Soft button: soft button * 4

4) Network

- WAN/PC: Support bridge mode
- Support PPPoE (ADSL,cable modem use for Internet connecting)
- Support VLAN (DATA VLAN and VOICE VLAN)
- Support L2TP VPN
- WAN support Primary and Secondary DNS
- WAN support DHCP Client
- Qos support Diffserv

5) Management and Maintenance

- Support safe mode and firmware updating under safe mode
- Support different level user management
- Configuration via web , keyboard
- Support multi-language
- Firmware and configuration updating via HTTP , FTP and TFTP
- Support system log and call log
- Firmware and configuration file auto provision

6) Protocol

- IEEE 802.3 /802.3 u 10 Base T / 100Base TX
- PPPoE: PPP over Ethernet
- WAN support DHCP Client
- SIP RFC3261, RFC3262, RFC3263, RFC3264, RFC3265, RFC2543, RFC3489, RFC3842, RFC3515, RFC2976, RFC3428, RFC2327, RFC2782, RFC1889
- TCP/IP: Transfer Control Protocol/Internet Protocol
- RTP: Real-time Transport Protocol
- RTCP:RTP Control Protocol
- VAD/CNG
- DNS: Domain Name Server
- TFTP:Trivial File Transfer Protocol
- HTTP:Hypertext Transfer Protocol
- FTP:File Transfer Protocol

7) Compliant Standard

- CE:EN55024,EN55022
- Comply with ROHS in EU
- Comply with ROHS in China



Explanation:

The letter “e” is the first letter of “environment: and “electronic”. The rim is a round with two arrow, stands for recycle. The number 20 stands for the years of environment protection. Please note the years of environment protection is not discarding year nor usage life.

8) Operating Requirement

- Operation temperature: 0 to 45° C (32° to 113° F)
- Storage temperature: -5° to 55° C (12° to 131° F)
- Humidity: 10 to 90% no dew

9) Packing List


Model	Phone	Handset	Handset line	Power adapter	Ethernet Cable	Manual CD	Feet underprop	EX20B
AT840	1	1	1	1,Standard accessory	1,1.5m	1	3	Optional
AT840 P	1	1	1	Optional accessory	1,1.5m	1	3	Optional

Note: Power adapter (Input: AC 100~240V, 50/60Hz; Output: 12V ,500mA;)

10) Installation

Use Ethernet cable to connect AT840’s WAN port and your computer. on the same switch, AT840 default to use DHCP to obtain IP from switch. Check AT840 IP by press MENU -> 9.Network ->2.Current IP (default password:123). Then open web browser and key in the IP, you will see the login page of AT840, the default username is admin for administrator and user for user, no password was set for them, you can set password in webpage by yourself.


Set up page for VoIP user only:




Feet installation instruction

1) Desktop position:


A. Put the bottom side of the IP phone upside and press the plate with letter "PUSH" into the slot, please refer the picture as below:



B. Press the other plate into the slot in accordance with the direction of the arrow




C. Repeat A and B. It is the right picture of putting on desk after fixing the two feet below:




D. Disassemble the feet:

Press the plate with word "PUSH" and pull the feet with the direction of arrow. When the plate is pull out of the slot (there will be a sound of "pa") you can take off the feet




2) On wall position



A. Put the bottom side of the IP phone upside and push the plate with letter "PUSH" into the slot, please refer the picture as below:



B. Push the other plate into the slot in accordance with the direction of the arrow




C. Repeat A and B. It is the picture of wall mounting after fixing the two feet below:




Attention: Please rotate the hook to the position as in picture with a coin or other tools

D. Disassemble the feet way:

Press the plate with word "PUSH" and pull the feet with the direction of arrow. When the plate is pull out of the slot (there will be a sound of "pa") you can take off the feet



2. Keypad of IP Phone



1) Describe of the buttons and Screen

Soft buttons	Press to select an feature shown in the soft button features.
Soft button features	Shows available choices based on current phone function displayed on the last line of LCD screen.
Status light	Shows the phone status, if the phone is standby, the LED is with light. If there is income calling, the LED will flicker. <ul style="list-style-type: none"> ➤ If the phone is starting ,the LED is flicker ➤ If the phone is standby, the LED is off ➤ If there is income calling, the LED will flicker. The frequency is 500ms off, 500ms on.
LCD Screen	Display screen for the phone: It shows the date, time, phone number, incoming caller's ID(if available),line/call status, extension numbers and the soft button features.

Line indicators	Shows extension number and status. There are three colors for LED: red, green and orange. <ul style="list-style-type: none"> ➤ If the line is registered, the LED shows green ➤ If the line is registered failed, the LED shows orange. Whenever it tries to register again after a while, the LED shows red and starts flashing. ➤ If the line has income calling, the LED shows red and flicker at 500ms off, 500ms on. ➤ If the line is on the calling , the LED shows red ➤ If the line disable for register, the LED is off.
Navigation button	Allows users to navigate(left, right, up, down).
Dial pad	Entering numbers, letters or characters.
BLF Key	All the function key can be defined as BLF key, Speed dial key etc.
Menu	Come into Keypad menu.
Volume buttons	Adjust the volume.
Speakerphone button	Pick up and hung up on the speakerphone mode, when pick up by speakerphone, the LED of the button is on.
Mute button	Mute the handset, headset or speakerphone by press the Mute button; this prevents the person on the active call form hearing what you or someone else in the room is saying. To cancel the Mute function, press the Mute button again. If Mute the voice, the LED is light on this button.
Headset button	Pick up and hung up on headset mode. When pick up by headset, the LED button will light on.
Voicemail button	Check the Voicemail status, if there are voicemail, the button will light on.

2) BLF indicator status

AT840 supports BLF in two ways, one is integrated on the IP phone, the other one is extended interface.

The BLF indicator status:

Table 1 Call /Line Appearance Button LEDs for BLF

LED Status	Description
Steady green	Call/line appearance is in idle status
Slow blinking red	Call/line appearance is ringing
Steady red	Call/line appearance is active

- When boot up,all the light blink for once.
- When there is a coming call,the corresponding line key and status light will blink.

3. Basic functions and operations

1) Answer the calls

When there is an incoming call, AT840 will remind user with ringing. There are 5 ways to answer the call

A. Answer by handset

Pick up the handset and talk with the caller. If you want to hang up, just put back the handset. When you are phoning with the handset and want to phone with hand-free mode, please press the hand-free button and put down the handset.

B. Hand-free mode

Press the speaker button in the phone and talk with callers by built-in Micro-phone and Speaker. If you want to hang up, please press the speaker button again. Lifting the handset in hand-free mode will switch to hand-free mode talking.

C. Answer by earphone

Keep your earphone connected with the RJ9 earphone jack, when there is an incoming call, press the earphone button on the IP phone and talk with the caller. If you want to hang up, please press the earphone button again. Pressing hand-free key can change to hand-free mode, and lifting the handset will change to hand-free mode.

2) Make Call

A. Use the handset

Pickup the handset, the LCD will show the current lines (user could switch between line1 to line4 by pressing the line button beside the LCD). Press soft key "dial" to send the number. When you hear the tones of "du~~du~~" with dialed number showed on the LCD, the called's phone is ringing. If the called answer the call, the phone call is established and the LCD will show the calling time and the called's number.

B. Answer the phone under hand-free mode

Press the Speaker Phone button, the LCD will show the current lines (user could switch between line1 and line2 by pressing the line button beside the LCD). User can input the number with the keyboard and press soft key "dial" to send the number. When caller hear the tones of "du~~du~~" with dialed number showed on the LCD, the called's phone is ringing. If the called answers the call, the phone call is established, and the LCD will show the calling time and the called's number.

C. Dial from phone book

1. Press " Menu" button and enter Directory->Personal Directory.Press "Select" to show the total amount in telephone.Use "up" and "down" keys to find the contact person.When you find the certain contact person, press" Dial" or just pickup the handset to call this number.
2. Pickup the handset, press "Dir", then select the contact person and press "Dial".

3) Speed dial

It's method for the phone in standby mode to dial number immediacy.

The method is as below:

- A. Dial-up the number in standby mode
- B. Press soft key "dial" to send out the number

Dial the number end with #, the number will be sent out immediately too,but only can used if pick up the handset or press handfree/headset key.

4) Multiple line dial-up

AT840 IP phone supports 4 SIP lines. That means user can register on 4 different sip accounts simultaneity in the same IP phone. The User can choose line1, line2, line 3 or line 4 by press corresponding line key, System default to use Line1 if you didn't choose line.

IP Phone be called:

AT840 maximum supports 8 concurrent calls. When there is an incoming call to the second line, LCD will show the incoming telephone number and line led will blinking. The User can press the "corresponding line key" , or press soft button "Hold" then press "Ans" to receive the second line call.

5) Hang up the phone

1) Headset hang up

When use handset mode calling, put back the handset to hang up.

2) Hands free hang up

When use hands free calling, press soft button "speaker phone" to hang up.

3) Earphone Hang up

When use Earphone calling, Press the soft button "headset" to hang up.

4) Hang up one line call

When 2 lines call simultaneous, press the hook will end the current call.

6) Call Transfer

➤ Attended call transfer

An attended call transfer allows a user to optionally transfer a call to a third party, after having a discussion with that third party.

During an active call, press the "xfer" soft key to place the current call on hold and to activate an idle line key. Dialed the transfer target number on the newly activated line. When the target is ringing or answered, press the "xfer" soft key again to complete the transfer.

Notes:

The case that transfer a call before the transfer target answer the phone is called semi-attended call transfer. This is different from a blind transfer which is described in the next subsection.

➤ Blind call transfer

A blind transfer allows the user to transfer a call without speaking with the receiver of the transferred call. For the user, the call ends as soon as the transfer target's phone number is dialed. The underlying mechanism is the user's phone sends the contact information for the transfer target to the phone of the other party on the call. The information is carried in a signaling message. When the message is sent, the user's phone is dropped from the call and the other party's phone automatically dials the transfer target.

To perform a blind transfer press the right navigation key then press "Bxfer" soft key and dial the target number,press "dial" to blind transfer the call to this target.

7) Message waiting indication(MWI)

The AT840 has an MWI key on the phone with an envelop ico. If user doesn't set the voicemail number, pressing MWI key will require the setup of voicemail number. Then pressing the MWI key can directly access the mailbox.

8) Mute calls

The user can mute the audio input into the phone when an audio device is switched on, by pressing the MUTE key. To un-mute, press the MUTE key again. If no audio device is on, pressing the MUTE key has no effect. When switching from the speaker phone to the handset, the phone is automatically un-muted.meanwhile Sip server must support RFC3515.

9) Call Hold

User can hold the current call by pressing soft button "Hold". And by pressing soft button "Resum" or press the line key, user can get back to the previous call. In 3-way conference call mode, user can also press this button to hold 3-way conference call, and if you press it again, user can go

back to 3-way conference mode. If hang up without exiting the status of hold. The conversation will not be canceled; the line is still on hold.

10) 3-Way Conference Calls

To initiate a conference call:

Press the Conf soft button in a conversation to hear a dial tone.

Enter the telephone number of the third party and press dial key to send it out.

- 1) Press the "Conf" soft button in Called party ringing state. When the third party answers the call, it will enter 3-way conference automatically.
- 2) After the third party answers the call, pressing "Conf" key to enter 3-way conference.
- 3) Press "Join" soft button to leave the conference and make the two other parties still in a conversation.
- 4) If user hangs up the call directly without pressing "Join" soft button, the conference will be ended and the three parties are hanging up.

11) Call History

AT840 supports 200 missed calls, 200 incoming calls and 200 dialed calls. When the storage is full, the latest call will update the history.

Press "redial" soft button when standby, all the incoming(->) outgoing(<-) and missed calls(!) will be listed. There is other way to check them:

➤ Missed call

Method 1:

- 1) When the LCD screen displays "(number) Missed call(s)", press soft button "Missed", then the screen shows all the "Missed Call".
- 2) Press navigation button to browse missed call history.
- 3) Choose the missed call record, press "Dial" soft button to call back it
- 4) Press "Delete" soft button to elect this item.
- 5) Press "Edit" soft button to edit this item.
- 6) Press right navigation key then press "Save" soft button to save this number.

Method 2:

- 1) Press the "MENU" button.
- 2) Press the navigation button to choose "Call History" and then press OK button.
- 3) Press the navigation button to choose "Missed Calls", press soft button OK.
- 4) Press the navigation button to browse the missed call record. If there is no record, the LCD screen display "List is Empty".

➤ Incoming call

- 5) Press the "MENU" button.

14) Check the Phone's IP

Press "MENU", default password is 123, then press 9 to enter "Network", you will see the network mode and current IP.

15) Dial Plan

The AT840 allows each extension to be configured with a distinct dial plan. The dial plan specifies how to interpret digit sequences dialed by the user, and how to convert those sequences into an outbound dial string.

The AT840 syntax for the dial plan closely resembles the corresponding syntax specified by MGCP and MEGACO. Some extensions are added that are useful in an end-point.

❖ Default: (xxxxxxxxxxxx.)

Which means allow dial out all kind of numbers.

❖ Dial plan format: (Dial_Plan 1| Dial_Plan 2| Dial_Plan 3|Dial_Plan 4)

For example: (*xx | [3469]11 | 0 | 00 | [2-9] xxxxxx | 1xxx [2-9] xxxxxxS0 | xxxxxxxxxxxx.)

The Dial_Plan parameters contain the actual dial plan scripts for each extension.

Dial Plan Digit Sequences:

The plans contain a series of digit sequences, separated by the '|' character. The collection of sequences is enclosed in parentheses, '('and ')'.

When a user dials a series of digits, each sequence in the dial plan is tested as a possible match. The matching sequences form a set of candidate digit sequences. As more digits are entered by the user, the set of candidates diminishes until only one or none are valid.

Any one of a set of terminating events triggers the AT840 to both accept the user-dialed sequence, and transmit it to initiate a call, or else reject it as invalid. The terminating events are:

- No candidate sequences remain: the number is rejected.
- Only one candidate sequence remains, and it has been matched completely: the number is accepted and transmitted after any transformations indicated by the dial plan, unless the sequence is barred by the dial plan (barring is discussed later), in which case the number is rejected.
- A timeout occurs: the digit sequence is accepted and transmitted as dialed if incomplete, or transformed as per the dial plan if complete.
- An explicit 'send' (user presses the '#' key): The digit sequence is accepted and transmitted as dialed if incomplete, or transformed as per the dial plan if complete.

The timeout duration depends on the matching state. If no candidate sequences are as yet complete (as dialed), the Interdigit_Long_Timeout applies. If a candidate sequence is complete, but there exists one or more incomplete candidates, then the Interdigit_Short_Timeout applies.

White space is ignored, and may be used for readability.

Digit Sequence Syntax:

Each digit sequence within the dial plan consists of a series of elements, which are individually matched to the keys pressed by the user. Elements can be one of the following:

Individual keys `0`, `1`, `2` . . . `9`, `*`, `#`.

The letter `x` matches any one numeric digit (`0` . . . `9`)

A subset of keys within brackets (allows ranges): `[set]` (e.g. [389] means `3` or `8` or `9`)

Numeric ranges are allowed within the brackets: digit `-[digit` (e.g. [2-9] means `2` or `3` or . . . or `9`)

Ranges can be combined with other keys: e.g. [235-8*] means `2` or `3` or `5` or `6` or `7` or `8` or `*`.

Element repetition:

Any element can be repeated zero or more times by appending a period (`.` character) to the element. Hence, `01.` matches `0`, `01`, `011`, `0111` . . . etc.

Subsequence Substitution:

A subsequence of keys (possibly empty) can be automatically replaced with a different subsequence using an angle bracket notation: `<` dialed-subsequence `:` transmitted-subsequence `>`. So, for example, `<<8:1650>xxxxxxx` would match `85551212` and transmit `16505551212`.

Intersequence Tones:

An "outside line" dial tone can be generated within a sequence by appending a `,` character between digits. Thus, the sequence `9, 1xxxxxxxx` sounds an "outside line" dial tone after the user presses `9`, until the `1` is pressed.

Number Barring:

A sequence can be barred (rejected) by placing a `!` character at the end of the sequence. Thus, `1900xxxxxxxx!` automatically rejects all 900 area code numbers from being dialed.

Interdigit Timer Master Override:

The long and short interdigit timers can be changed in the dial plan (affecting a specific line) by preceding the entire plan with the following syntax:

Long interdigit timer: `L` `:` delay-value `,`

Short interdigit timer: `S` `:` delay-value `,`

Thus, "L=8, (. . .)" would set the interdigit long timeout to 8 seconds for the line associated with this dial plan. And, "L: 8, S: 4, (. . .)" would override both the long and the short timeout values.

Local Timer Overrides:

The long and short timeout values can be changed for a particular sequence starting at a particular point in the sequence. The syntax for long timer override is: 'L' delay-value ". Note the terminating space character. The specified delay-value is measured in seconds. Similarly, to change the short timer override, use: 'S' delay-value <space>.

Pause:

A sequence may require an explicit pause of some duration before continuing to dial digits, in order for the sequence to match. The syntax for this is similar to the timer override syntax: 'P' delay-value <space>. The delay-value is measured in seconds.

This syntax allows for the implementation of Hot-Line and Warm-Line services. To achieve this, one sequence in the plan must start with a pause, with a 0 delay for a Hot Line, and a non-zero delay for a Warm Line.

Implicit sequences:

The SPA implicitly appends the vertical code sequences entered in the Regional parameter settings to the end of the dial plan for both line 1 and line 2. Likewise, if Enable_IP_Dialing is enabled, then ip dialing is also accepted on the associated line.

Examples:

The following dial plan accepts only US-style 1 + area-code + local-number, with no restrictions on the area code and number.

```
(1 xxx xxxxxxxx)
```

The following also allows 7-digit US-style dialing, and automatically inserts a 1 + 212 (local area code) in the transmitted number.

```
(1 xxx xxxxxxxx | <:1212> xxxxxxxx)
```

For an office environment, the following plan requires a user to dial 8 as a prefix for local calls and 9 as a prefix for long distance. In either case, an "outside line" tone is played after the initial 8 or 9, and neither prefix is transmitted when initiating the call.

```
(<9, :> 1 xxx xxxxxxxx | <8,:1212> xxxxxxxx )
```

The following allows only placing international calls (011 call), with an arbitrary number of digits past a required 5 digit minimum, and also allows calling an international call operator (00). In addition, it lengthens the default short interdigit timeout to 4 seconds.

```
S: 4, (00 | 011 xxxxx x.)
```

The following allows only US-style 1 + area-code + local-number, but disallows area codes and local numbers starting with 0 or 1. It also allows 411, 911, and operator calls (0).

(0 | [49]11 | 1 [2-9] xx [2-9] xxxxxx)

The following allows US-style long distance, but blocks 9xx area codes.

(1 [2-8] xx [2-9] xxxxxx)

The following allows arbitrary long distance dialing, but explicitly blocks the 947 area code.

(1 947 xxxxxxxx! | 1 xxx xxxxxxxx)

The following implements a Hot Line phone, which automatically calls 1 212 5551234.

(S0 <:12125551234>)

The following provides a Warm Line to a local office operator (1000) after 5 seconds, unless a 4 digit extension is dialed by the user.

(P5 <:1000> | xxxx)


4. Web settings

Enter AT840 IP addresses in the web browser to go to the log on page, then you will access AT840's user webpage.

Click "admin" which is on the right corner to enter administrator webpage.



1) System status



This page shows the IP phone's system status.

Product Information shows the product name, protocol, software and hardware version, Mac address and serial number.

Network Information shows the type, IP, netmask, gateway, DNS, host name, domain and VPN information.

Account 1/2/3/4 Information shows whether the account is registered and the proxy, user ID ,message waiting on or off and the registration time.

The Version shows the current firmware version.

2) Network

1.1. Basic

There are 3 ways to connect to the internet DHCP, Static and PPPoE, please choose one according to your own situation.

Network mode: you can choose DHCP, Static and PPPoE

DHCP: AT840 default to use DHCP to obtain dynamic IP.

Static: If you want to set your ip as static, you should fill ip, netmask, gateway and DNS information.

PPPoE: If connect AT840 to modem, you should fill ADSL account and the password which assigned by your network service provider.

1.2. Advance

➤ Web Server

Web Server

Enable Web Server :

Admin Password : User Password :

HTTP Port :

✓ Enable Web Server: enable or disable web access. If choose "no", you can not access AT840

webpage.

- ✓ Admin password: set admin webpage access password.(username:admin)
- ✓ User password: set user webpage access password.(username:user)
- ✓ HTTP port: set port for HTTP(default is 80)

For example, the AT840's ip is 192.168.1.223

HTTP port was set as 100, you have to type "http://192.168.1.223:100" in web browser to enter AT840 webpage.

❖ **VPN**

VPN

VPN Enable :	<input type="text" value="no"/>	VPN Type :	<input type="text" value="L2TP Tunnel"/>
Server Address :	<input type="text"/>		
User Name :	<input type="text"/>	Password :	<input type="text"/>

- ✓ VPN Enable: whether enable VPN
- ✓ VPN Type: only support L2TP VPN
- ✓ Server address: VPN server address
- ✓ Username: VPN account's username
- ✓ Password: VPN account's password

After apply, the phone will reboot. The VPN ip will show on the System Status page.

❖ **VLAN**

VLAN

You should receive the tagging values of a virtual LAN from your provider. Wrong settings will require factory reset

Use VLAN Tagging :	<input type="text" value="no"/>		
Voice VLAN Identifier(1..4094) :	<input type="text" value="1"/>	Voice VLAN Priority :	<input type="text" value="0"/>
Data VLAN Identifier(1..4094) :	<input type="text" value="1"/>	Data VLAN Priority :	<input type="text" value="0"/>

- ✓ Use Vlan Tagging: vlan tag or untag
- ✓ Voice VLAN Identifier(1..4094) : Assign VLAN id for voice stream between 1 to 4094
- ✓ Voice VLAN Priority : the degree is 0-7, 7 is the highest priority.
- ✓ Data VLAN Identifier(1..4094) : Assign VLAN id for data stream between 1 to 4094
- ✓ Data VLAN Priority : the degree is 0-7, 7 is the highest priority.

➤ **Port Link**

Port Link

WAN Port Link : PC Port Link :

Choose the type of the WAN/PC network port link

- ✓ WAN Port Link: Auto negotiate, full duplex 10Mbps, full duplex 100Mbps, half duplex 10Mbps, half duplex 100Mbps.
- ✓ PC Port Link: Auto negotiate, full duplex 10Mbps, full duplex 100Mbps, half duplex 10Mbps, half duplex 100Mbps.

➤ **Qos**

Qos

SIP Qos(0..63) : Voice Qos(0..63) :

Quality of service

- ✓ SIP Qos: Quality of service for SIP (Diffserv)
- ✓ Voice Qos: Quality of service for RTP (Diffserv)

➤ **Syslog**

Syslog

Enable Syslog : Log Level :
 Syslog Server : Port :

- ✓ Enable Syslog: whether to enable syslog.
- ✓ Log level: None, Alert, Critical, Error, Warning, Notice, Info, Debug. The debug level is the most detailed.
- ✓ Syslog Server: Syslog Server address.
- ✓ Port: Syslog port, which usually is 514.

3) SIP Setting

➤ **Sip Timer Values**

Sip Timer Values

Sip T1 : Sip T2 :
 Sip T4 :
 Reg Retry Intvl : Sub Retry Intvl :

- ✓ Sip T1: RFC 3261 T1 value (RTT Estimate). Range: 0 - 64 sec
- ✓ Sip T2: RFC 3261 T2 value (Maximum retransmit interval for non-INVITE requests and INVITE responses). Range: 0 - 64 sec
- ✓ Sip T4: RFC 3261 T4 value (Maximum duration a message will remain in the network). Range: 0 - 64 sec
- ✓ Reg Retry Intvl: Interval to wait before the phone retries registration again after encountering a failure condition during last registration
- ✓ Sub Retry Intvl: Interval to wait before the phone retries registration again after encountering a failure condition during last registration.

➤ **RTP Parameters**

RTP Parameters

RTP Port Min :	<input type="text" value="16384"/>	RTP Port Max :	<input type="text" value="16482"/>
RTP Packet Size(ms) :	<input type="text" value="10"/>		

- ✓ RTP Port Min: Minimum port number for RTP transmission and reception. <RTP Port Min> and <RTP Port Max> should define a range that contains at least 2 even number ports . Defaults to 16384
- ✓ RTP Port Max: Maximum port number for RTP transmission and reception. <RTP port Min> and <RTP Port Max> should define a range that contains at least 2 even number ports. Defaults to 16482.
- ✓ RTP Packet Size(ms): Packet size in milliseconds, which can be 10, 20, 30, 40, 60.

➤ **SDP Payload Types**

SDP Payload Types

AVT Dynamic Payload :	<input type="text" value="101"/>	G729b Dynamic Payload :	<input type="text" value="18"/>
G726r16 Dynamic Payload :	<input type="text" value="108"/>	G726r24 Dynamic Payload :	<input type="text" value="97"/>
G726r32 Dynamic Payload :	<input type="text" value="2"/>	G726r40 Dynamic Payload :	<input type="text" value="96"/>
iLBC Dynamic Payload :	<input type="text" value="98"/>	iLBC Mode :	<input type="text" value="13.3 kBit/s"/>
Lin16-16 Dynamic Payload :	<input type="text" value="102"/>		
G711a Codec Name :	<input type="text" value="PCMA"/>	G711u Codec Name :	<input type="text" value="PCMU"/>
AVT Codec Name :	<input type="text" value="telephone-event"/>	G722 Codec Name :	<input type="text" value="G722"/>
G723 Codec Name :	<input type="text" value="G723"/>	G723 Mode :	<input type="text" value="6.3 kBit/s"/>
G729ab Codec Name :	<input type="text" value="G729"/>		
G726-16 Codec Name :	<input type="text" value="G72616"/>	G726-24 Codec Name :	<input type="text" value="G72624"/>
G726-32 Codec Name :	<input type="text" value="G72632"/>	G726-40 Codec Name :	<input type="text" value="G72640"/>
iLBC Codec Name :	<input type="text" value="iLBC"/>	Lin16-16 Codec Name :	<input type="text" value="L16"/>

- The configured dynamic payloads are used for outbound calls only where the SPA presents

the SDP offer. For inbound calls with a SDP offer, SPA will follow the caller's dynamic payload type assignments.

- ✓ AVT Dynamic Payload---AVT dynamic payload type. Defaults to 101
- ✓ G729b Dynamic Payload---G729b dynamic payload type. Defaults to 18
- ✓ G726r 16 Dynamic Payload---G726r 16 dynamic payload type. Defaults to 108
- ✓ G726r 24 Dynamic Payload---G726r 24 dynamic payload type. Defaults to 97
- ✓ G726r 32 Dynamic Payload---G726r 32 dynamic payload type. Defaults to 2
- ✓ G726r 40 Dynamic Payload---G726r 40 dynamic payload type. Defaults to 96
- ✓ iLBC Dynamic Payload---iLBC dynamic payload type. Defaults to 98
- ✓ iLBC Mode---iLBC codec code rate, which can be 13.3kbit/s, 15.2kbit/s
- ✓ Lin16-16 Dynamic Payload---Lin16-16 dynamic payload type, defaults to 102
- ✓ G711a Codec Name---G711a codec name used in SDP, defaults to PCMA
- ✓ G711u Codec Name---G711u codec name used in SDP, defaults to PCMU
- ✓ AVT Codec Name---AVT codec name used in SDP, defaults to telephone-event
- ✓ G722 Codec Name---G722 codec name used in SDP, defaults to G722
- ✓ G723 Codec Name---G723 codec name used in SDP, defaults to G723
- ✓ G723 Mode---G723 codec code rate, which can be 6.3kbit/s, 5.3kbit/s
- ✓ G729ab Codec Name---G729ab codec name used in SDP, defaults to G729
- ✓ G726-16 Codec Name---G726-16 codec name used in SDP, defaults to G72616
- ✓ G726-24 Codec Name---G726-24 codec name used in SDP, defaults to G72624
- ✓ G726-32 Codec Name---G726-32 codec name used in SDP, defaults to G72632
- ✓ G726-40 Codec Name---G726-40 codec name used in SDP, defaults to G72640
- ✓ iLBC Codec Name---iLBC codec name used in SDP, defaults to iLBC
- ✓ Lin16-16 Codec Name---Lin16-16 codec name used in SDP, defaults to L16

➤ **NAT Support Parameters**

NAT Support Parameters

Enable Stun : Stun Server :

- ✓ Enable Stun: Whether to use stun to discover NAT mapping.
- ✓ Stun Server: Stun server to contact for NAT mapping discovery.

4) Account

Account1/Account2/Account3/Account4

➤ **SIP**

SIP

Enable :	<input type="text" value="Yes"/>		
Display Name :	<input type="text" value="5060"/>	User ID :	<input type="text" value="5060"/>
Authenticate ID :	<input type="text" value="5060"/>	Password :	<input type="text" value="...."/>
SIP Server :	<input type="text" value="172.16.0.55"/>	SIP Port :	<input type="text" value="5060"/>
Use Outbound Proxy :	<input type="text" value="No"/>		
Outbound Proxy Server :	<input type="text"/>	Outbound Proxy Port :	<input type="text" value="5060"/>
Register Expires :	<input type="text" value="300"/>	Subscribe Expires :	<input type="text" value="3600"/>
Transport Type :	<input type="text" value="UDP"/>	SIP 100Rel Require :	<input type="text" value="No"/>
Session Timer Enable :	<input type="text" value="Yes"/>	Early Update Enable :	<input type="text" value="No"/>
Caller ID Display :	<input type="text" value="No"/>	AutoSubscribeMWIEnable :	<input type="text" value="Yes"/>
Server List :	<input type="text" value="Broadsoft"/>	Dns Mode :	<input type="text" value="Yes"/>
Bf List Uri :	<input type="text"/>		

- ✓ Enable: whether enable this sip register.
- ✓ Display Name: This name will display on your screen. It will show the User ID instead if leave display name as blank.
- ✓ User ID: Username of sip account.
- ✓ Authenticate ID: normally is the same with User ID, can also leave it as blank.
- ✓ Password: Password of sip account.
- ✓ Server Server: SIP server address , support both IP address and domain name.
- ✓ Server Port: SIP server port , default is 5060.
- ✓ Use Outbound Proxy: Whether to use outbound proxy.
- ✓ Outbound Proxy Server: Normally the Proxy server is the same as SIP server. If they are different then fill in the correct information that provided by ISP.
- ✓ Outbound Proxy Port: Set your proxy server port.
- ✓ Register Expires: register expire time, default is 60 seconds. AT840 will auto configure this expire time to the server recommended setting if it is different from the SIP server.
- ✓ Transport Type: UDP/TCP/TLS.
- ✓ SIP 100Rel Require : If enable, phone need the other side to respond PRACK to reliable transmission of provisional responses (18x).
- ✓ Session Timer Enable: Whether to enable session timer extension for this account. Default is no.
- ✓ Early Update Enable: this parameter control the account to support receiving Early Update.
- ✓ CallerID Display: this parameter is used to supported the P-Asserted-Identity header.

- ✓ AutoSubscribeMWI Enable: Enable this account to subscribe for message summary automatically.
- ✓ Server List: the SIP server list supported, can be common and Broadsoft, default to common.
- ✓ DNS mode: enable the account to use DNS SRV query. Default to no which use DNS A query.
- ✓ Request URI: the Broadworks BLF uri to request.

➤ Codec Configuration

Codec Configuration

G711A :	<input type="text" value="Yes"/>	G711U :	<input type="text" value="Yes"/>
AVT :	<input type="text" value="Yes"/>	G722 :	<input type="text" value="Yes"/>
G723 :	<input type="text" value="Yes"/>	G729ab :	<input type="text" value="Yes"/>
iLBC :	<input type="text" value="Yes"/>	G726-16 :	<input type="text" value="Yes"/>
G726-24 :	<input type="text" value="Yes"/>	G726-32 :	<input type="text" value="Yes"/>
G726-40 :	<input type="text" value="Yes"/>		
Prefer Codec :	<input type="text" value="G711u"/>	User Prefer Codec Only :	<input type="text" value="No"/>
DTMF Tx Method :	<input type="text" value="RFC2833"/>		

- ✓ G711A: enable or disable G711A codec support in this account.
- ✓ G711U: enable or disable G711U codec support in this account.
- ✓ AVT: enable or disable AVT codec support in this account.
- ✓ G722: enable or disable G722 codec support in this account.
- ✓ G723: enable or disable G723 codec support in this account.
- ✓ G729ab: enable or disable G729ab codec support in this account.
- ✓ iLBC: enable or disable iLBC codec support in this account.
- ✓ G726-16: enable or disable G726-16 codec support in this account.
- ✓ G726-24: enable or disable G726-24 codec support in this account.
- ✓ G726-32: enable or disable G726-32 codec support in this account.
- ✓ G726-40: enable or disable G726-40 codec support in this account.
- ✓ Prefer Codec: Select a preferred codec for all calls. (G711u/G711a/G729/G722/G723/G726-16/G726-24/G726-32/G726-40/Lin16-16)
However, the actual codec used in a call still depends on the outcome of the codec negotiation protocol.
- ✓ User Prefer Codec Only: Only use the preferred codec for all calls. The call will fail if the far end does not support this codec.
- ✓ DTMF Tx Method: select the method to transmit DTMF signals to the far end: Inband, rfc2833, INFO. Defaults to RFC2833.

➤ **Call Feature Setting**

Call Feature Setting

Message Waiting :	<input type="text" value="yes"/>	Voice Mail Number :	<input type="text" value="6750"/>
Pickup Service Code :	<input type="text" value="*8"/>		
UDP Keep Alive Enable :	<input type="text" value="no"/>	UDP Keep Alive Intvl :	<input type="text" value="15"/>
Default Ring :	<input type="text" value="2"/>		
SRTP :	<input type="text" value="Off"/>		

- ✓ Message Waiting: whether to prompt if there is a voicemail.
- ✓ Voice Mail Number: if you set voicemail number, then you can just press the voicemail key to auto dial voicemail number then enter voicemail box.
- ✓ Pickup Service Code: set Pickup Service Code according to the service settings.
- ✓ UDP Keep Alive Enable: Enabel UDP keep alive, to detect if the server is still available.
- ✓ UDP Keep Alive Intvl: Set expire time of the keep alive UDP.
- ✓ Default Ring: which ring to select for this account.
- ✓ SRTP: Secure Real Time Protocol. Enable the phone to encrypt the RTP packets.

➤ **Dial Plan**

Dial Plan

Dial Plan :

- ✓ Dial Plan: Configure dial rule for this sip account, please refer to [dial plan](#).

5) Phone Setting

5.1. Preference

Language

Language :

Output Volume(1~8)

Handset Volume :

SpeakerPhone Volume :

Headset Volume :

Input Gain

Handset Gain :

SpeakerPhone Mic Gain :

Headset Gain :

LCD

LCD Contrast :

Backlight Time(Seconds) :

➤ Language

Support customizable multi-language.

➤ Output Volume(1~8)

- ✓ Handset Volume: Specify handset volume grade
- ✓ SpeakerPhone Volume: Specify hand-free volume grade
- ✓ Headset Volume: Specify headset volume grade

➤ Input Gain

- ✓ Handset Gain: Specify handset gain, the bigger the gain is the louder the other end heard.
- ✓ SpeakerPhone Volume: Specify hand-free gain, the bigger the gain is the louder the other end heard.
- ✓ Headset Volume: Specify headset gain, the bigger the gain is the louder the other end heard.

➤ LCD

- ✓ LCD Contrast
- ✓ Backlight Time(Seconds)

➤ Control Timer Values(Seconds)

Control Timer Values(Seconds)

Interdigit Long Timer: Interdigit Short Timer:
 Recorder Delay:

- ✓ Interdigit Long Timer: Long timeout between entering digits when dialing. Range: 0 - 64 sec
- ✓ Interdigit Short Timer: Short timeout between entering digits when dialing. Range: 0 - 64 sec
- ✓ Recorder Delay: Delay after far end hangs up before reorder tone is played. 0 = plays immediately, inf = never plays. Range: 0 - 255 sec

➤ **Date And Time**

Date And Time

NTP

NTP Server:

Time Zone:

Daylight Saving Time:

Daylight Saving Time Rule:

Manual

Set Local Date(YYYY/mm/dd):

Set Local Time(HH:mm:ss):

● **NTP**

- ✓ NTP Server: Network time protocol service, default is pool.ntp.org.
- ✓ Time Zone: Choose your own time zone.
- ✓ Daylight Saving Time: whether to enable Daylight saving time.
- ✓ Daylight Saving Time Rule: This parameter is a rule with three fields, each field is separated by semicolon; as show below:
 Start=<start-time>; end=<end-time>; save=<save-time>

<start-time> and <end-time> specify the start and end date of daylight saving time, month/date/weekand <save-time> is the amount of hour/min/sec to add to the current time during daylight saving period. The <save-time> value can be preceded by a negative (-) sign if subtraction is desired instead of addition.

If <weekday > is 0, it means the date to start or end daylight saving is at exactly the given date. In that case, the <day> value must not be negative. If<weekday >is not zero, then the daylight

saving starts or ends on the <weekday >on or after the given date if <day> is positive, or on or before the given date if <day> is negative. If <day> is -1, it means the <weekday> on or before the end-of-the - month (in other words the last occurrence of <weekday> in that month)

Optional values inside [] are assumed to be 0 if they are not specified. Midnight means 0:0:0 of the given date.

E.G. start=4/1/7/8:00:00;end=10/1/7/9:00:00;
 save=-1Start time is 1st April, Sunday, 8:00:00 am.
 End time is 1st October, Sunday, 9:00:00 am.
 The display time will be one hour early than the standard time.

● **Manual**

- ✓ Set Local Date(YYYY/mm/dd): manually set local date: year/month/day
- ✓ Set Local Time(HH:mm:ss) : manually set local time: hour/minute/second

5.2. Line

Phone Setting / Line

	Account	Short Name
Line Key 1 :	1 <input type="button" value="v"/>	<input style="width: 95%;" type="text"/>
Line Key 2 :	2 <input type="button" value="v"/>	<input style="width: 95%;" type="text"/>
Line Key 3 :	3 <input type="button" value="v"/>	<input style="width: 95%;" type="text"/>
Line Key 4 :	1 <input type="button" value="v"/>	<input style="width: 95%;" type="text"/>

Set name for each line showed on LCD, if keep it as blank, it will use phone SIP account user ID as name.

5.3. Features

➤ **Speed Dial**

Speed Dial

Speed Dial 2 :	<input type="text"/>	Speed Dial 3 :	<input type="text"/>
Speed Dial 4 :	<input type="text"/>	Speed Dial 5 :	<input type="text"/>
Speed Dial 6 :	<input type="text"/>	Speed Dial 7 :	<input type="text"/>
Speed Dial 8 :	<input type="text"/>	Speed Dial 9 :	<input type="text"/>

Set speed dial for 2-9. For example, set 6750 for key 2, then you can press 2 then press softkey "dial", 6750 will be dial out immediately.

➤ **Call Forward**

Call Forward

Always Target:	<input type="text"/>	Busy Target:	<input type="text"/>
No Answer :	<input type="text"/>		
After Ring Time(Seconds) :	<input type="text" value="5"/>		

- ✓ Always Target: every incoming call will forward to this target.
- ✓ Busy Target: The incoming call will forward to this target when AT840 is busy.
- ✓ No Answer: The incoming call will forward to this target when there is no answer.
- ✓ After Ring Time(Seconds): After this time, the phone will be forward to no answer target.

Do Not disturb

Enable : ▼

Block Call ID

Enable : ▼

Block Anc Call

Enable : ▼

Auto Answer

Enable : ▼

Others

Send Key : ▼

➤ **Do Not Disturb**

When enable Do Not Disturb on the webpage or on the phone, all the incoming call will be no answer, and Missed Call information will show on the LCD.

➤ **Block Call ID**

When enable Block caller ID, AT840 will call others as anonymous.

➤ **Block Anc Call**

When enable block anonymous call, AT840 will reject anonymous caller.

➤ **Auto Answer**

When a call in coming, the phone will answer the call by handfree automatically.

➤ **Others**

Define the Send key as # or *, press # or * after dial number, then number will be sent out immediately.

5.4. Voice

Phone Setting / Voice

Echo Cancellation

VAD: CNG:

Jitter Buffer

Type:

Min Delay: Max Delay:

Normal Delay:

➤ **Echo Cancellation**

- ✓ VAD: Select it or not to enable or disable VAD(Voice Active Detection). If enable VAD, G729 Payload length could not be set over 20ms.
- ✓ CNG: Select it or not to enable or disable CNG(Comfort Noise Generator)

➤ **Jitter Buffer**

- ✓ Type: Choose type of jitter buffer. The SPA can buffer incoming voice packets to minimize out-of-order packet arrival. This process is known as jitter buffer.
- ✓ Min Delay: The minimum delay of the jitter buffer.
- ✓ Max Delay: The maximum delay of the jitter buffer.
- ✓ Normal Delay: It is used as fixed delay which should be between min delay and max delay.After finishing, click submit button to save changes..

5.5. Ring

Notes: Ring tone must be wav file, 8k sampling rate, 8 Bit u-law compression. File size should < 200Kbytes

Upload Ring Tone 浏览...

Ring Tone Type

Administer can upload 2 user define ring for AT840. The ring file could be wav(8k, 8bit, u-law) and no larger than 200k.

5.6. Tone

Phone Setting / Tone

Tone

Country Stands :

Dial Tone :

Outside Dial Tone :

Busy Tone :

Reorder Tone :

Off Hook Warning Tone :

Ring Back Tone :

MWI Dial Tone :

Holding Tone :

Conference Tone :

Set the ToneScript for each tone.

For example, MWI Dial Tone: [350@-19,440@-19;2\(.1/,1/1=2\);10\(* / 0 / 1 + 2\)](#)

Frequency1, Frequency2 ;Cadence Section1;Cadence Section2

[350@-19](#): Frequency1 is 350HZ at -19dBm

[440@-19](#): Frequency2 is 440HZ at -19dBm

[2\(.1/,1/1=2\)](#): Cadence Section length is 2s, 0.1s on, 0.1s off, with frequencies 1 and 2

[10\(* / 0 / 1 + 2\)](#): Cadence Section length is 10s, always on(* means always, 0 means never), with frequencies 1 and 2.

AT840 Series User Manual

- ✓ Country stands: select a country standard tone as default.
- ✓ Dial Tone: Played when prompting the user to enter a phone number.
- ✓ Outside Dial Tone: An alternative to <Dial Tone> usually used to prompt the user to enter an external phone number (versus an internal extension). This is triggered by a “,” character encountered in the dial plan.
- ✓ Busy Tone: Played when a 486 RSC is received for an outbound call.
- ✓ Reorder Tone: Played when an outbound call has failed or after the far end hangs up during an established call.
- ✓ Off Hook Warning Tone: Played when the subscriber does not place the handset on the cradle properly.
- ✓ Ring Back Tone: Played for an outbound call when the far end is ringing.
- ✓ MWI Dial Tone: This tone is played instead of <Dial Tone> when there are unheard messages in the subscriber’s mail box.
- ✓ Holding Tone: Indicate to the local user that the far end has placed the call on hold.
- ✓ Conference Tone: Plays to all parties when a Three way conference is in progress.

5.7. Programmable key

Phone Setting / Programmable Key

Mode	Account	Number
Key 1	SpeedDial ▼	Account 1 ▼ 6002
Key 2	BLF ▼	Account 1 ▼ 6001
Key 3	BLF ▼	Account 2 ▼ 8001
Key 4	Redial ▼	Account 1 ▼
Key 5	CallPark ▼	Account 1 ▼ *8
Key 6	None ▼	Account 1 ▼
Key 7	None ▼	Account 1 ▼
Key 8	None ▼	Account 1 ▼
Key 9	None ▼	Account 1 ▼

✓ Submit
↶ Reset

- ✓ Event:
 - None: Do not use this BLF key
 - Hold: hold a call
 - Xfer: transfer a call
 - Conf: make 3 way conference
 - DND: Do not disturb(can make call but can not receive call).
 - CFWD: call forward
 - Speed dial: Speed dial, need to fill a speed dial number.
 - BLF: Busy lamp field, need to fill a BLF number to monitor.

When the BLF number is ringing , the BLF key will turn to red and blink.

When the BLF number is during a call, the BLF key will stay for red.

The BLF key will be yellow, if the BLF number is idle. And you can press the Key to call the number(like speed dial).

- CallPickup: Pick up the sb's call which in the same pickup group.
- CallPark: Park a call on the server.
- SMS: message
- Redial: redial the number.
- ✓ Account: which account you want to used.
- ✓ Number: which number to set for CFWD, speed dial, BLF etc.

5.7. Ext Key

Phone Setting / Ext Key

Attendant Module 1

	Mode	Account	Number
Key 1	BLF	Account 1	501
Key 2	BLF	Account 1	502
Key 3	BLF	Account 1	503
Key 4	BLF	Account 1	504
Key 5	BLF	Account 1	505
Key 6	BLF	Account 1	506
Key 7	BLF	Account 1	507
Key 8	BLF	Account 1	508
Key 9	BLF	Account 1	509
Key 10	BLF	Account 1	510
Key 11	BLF	Account 1	511
Key 12	BLF	Account 1	512

After connect extension module to AT840's EXT port, AT840 will auto detect the extension module. There are 20 keys on each extension module.

- ✓ Event:
 - None: Do not use this BLF key
 - Speed dial: Speed dial, need to fill a speed dial number.
 - BLF: Busy lamp field, need to fill a BLF number to monitor.

When the BLF number is ringing , the BLF key will turn to red and blink.

When the BLF number is during a call, the BLF key will stay for red.

The BLF key will be yellow, if the BLF number is idle. And you can press the Key to call the

number(like speed dial).











- ✓ Account: which account you want to used.
- ✓ Number: which number to set for CFWD, speed dial, BLF etc.

6) Update

6.1. Manual Update

Update / Manual Update

Bootloader Version: 2.3
 Firmware Version: 2.2.3.11166
 Hardware Version:

Boot Loader:	<input type="text"/>	浏览...	 Upgrade	
Firmware:	<input type="text"/>	浏览...	 Upgrade	
Language Package:	<input type="text"/>	浏览...	 Upgrade	 Download
Configuration:	<input type="text"/>	浏览...	 Upgrade	 Download
Phone Book:	<input type="text"/>	浏览...	 Upgrade	 Download
Attendant Keys:	<input type="text"/>	浏览...	 Upgrade	 Download

- ✓ Boot Loader: Download Boot file on ATCOM's webpage, then select the file from your PC to upgrade.
- ✓ Firmware: Download firmware on ATCOM's webpage, then select firmware from your PC to upgrade.
- ✓ Language Package: Download Language Package on ATCOM's webpage, then select the package from your PC to upgrade. Please note that, the language package you updated will replace the existed language on the phone.
- ✓ Configuration: Upgrade or download config.xml file.
- ✓ Phone Book: Upgrade or download phonebook.xml
- ✓ Attendant Keys: Upgrade or download attendant_keypad.xml

6.2. Reset & Reboot




✓ **Reset**

Reset will set AT840 to factory default, please backup the config.xml, phonebook.xml and attendant_keypad.xml before reset.

✓ **Reboot**

Reboot will terminate all active calls, and cost a little time.


7) Phone Book



- ✓ **New Contact:** Add a new phonebook item.
 - ✓ **Mode:** Directory or Blacklist. Numbers in Blacklist will be reject when calling.
 - ✓ **Name:** name of a number , when the call of this number comes in the LCD will show the name.
 - ✓ **Number:** phone number.
 - ✓ **Submit:** Submit to apply the change.
 - ✓ **Reset:** Cancel the inputting.
- Click **【Delete】** to delete the item.

Notice: Maximum records of phone book is 200.

8) Call Log



	Name	Number	Time
1:	Bely	6003	25/05 19:13
2:	Amy	6002	25/05 19:13
3:	voicemail	6750	25/05 19:13
4:	8	8	25/05 19:12

- ✓ Redial: Record of dial list, maximum 200 items.
- ✓ Received: Record of received list, maximum 200 items.
- ✓ Missed: Record of Missed list, maximum 200 items.

5. FAQ & Trouble Shooting

1) Frequently Asked Questions

1.1 How to make a factory reset

There are three ways to make a factory reset:

A. Factory reset from keyboard, steps are:

1. Press soft key "MENU";
2. Find and select "Factory Reset" ;
3. Press "OK", then the phone will restart automatically and factory reset.

B. Factory reset through web, please refer to [Reset & Reboot](#);

1.2 Upgrade firmware under safe mode

If the phone could not start up normally, upgrade firmware under safe mode. Steps are:

1. Build a TFTP server and set its IP address as 192.168.1.200;
2. Copy the firmware to the root directory of the TFTP server and modify the file name as

AT840.FW;

3. Make sure the TFTP server and the phone are contacting with the same switch and reachable to each other;
4. Long hold “#” key and start up the phone until the LCD display “Upgrading...”;
5. The phone will download the firmware from the TFTP server;
6. After the download is done, the phone will upgrade automatically;
7. After the update is finished, the phone will start up with the configuration of factory reset.

1.3 How to make direct IP call

When hook off/ pressing speaker or headset key,

1. Press right negative key and press the third softkey "number" twice to switch to "IP".
2. Using * key to inputting ".". If user wants to dial 192.168.1.100, then press 192*168*1*100.
3. After inputting the IP address, press dial key to dial it out.

2) Trouble Shooting

2.1 The phone can't register successfully

- A. Check the IP address, and if the mode of WAN port is DHCP, please make sure the DHCP server is in service.
- B. Check the gateway.
- C. Check the DNS.
- D. Make sure the information of the account is consistent with which offered by the service supplier.
- E. Make sure the SIP server is on.
- F. Check the port of the SIP server whose default value is 5060.

2.2 The phone can't obtain IP address

- A. Make sure the cable has been connected to the WAN port of the phone.
- B. Make sure the cable and the switch's port that connected with the cable is available.
- C. Make sure the DHCP server is on and there are some assignable IP addresses in the address pool.
- D. Try to change the WAN port mode as Static.

2.3 Only one part can hear the voice during the call

- A. Make an IP dial-up call to make sure the telephone receiver and Mic are normal.
- B. Enable STUN on web page.
- C. Set STUN server as `stun.3cx.com`.
- D. Click on "submit" and wait for the phone to restart.
- E. Try to make calls again.